

Truck Powertrain

Engine / Diesel Engine

All internal lubricated parts:

- Camshaft & cam bearings
- Connecting rods & rod bearings
- Crankshaft & main bearings
- Cylinder heads
- Diesel fuel injectors
- Diesel injection pump
- Engine block
- Gears or chain
- Lifters
- Main engine oil pump
- Pistons & piston rings
- Push rods
- Rocker arms
- Valves, valve springs & valve push rods

Transmission

All internal lubricated parts:

- Bell housing
- Torque converter
- Transmission case

Differential

All internal lubricated parts:

- Differential housing
- Differential cover

Transfer Case

All internal lubricated components in transfer case.

Seals & Gaskets

Internal leaks of:

- Cylinder head gasket
- Intake manifold gasket
- All other seals & gaskets only in conjunction with a covered repair

Fluids & Filters / Diagnostics

- Any fluids & filters required for a covered repair according to OEM specifications
- Reasonable diagnostic charges up to \$75

Truck Silver

Includes all Truck Powertrain coverage and...

Engine

- Flywheel/flex plate
- Water pump

Drive Axle

All internal lubricated parts:

- CV joints
- Universal joints & wheel bearings

Electrical

- Alternator
- Front windshield wiper motor
- Power door lock actuators
- Power seat motors
- Power window motors
- Starter motor & solenoid
- Voltage regulator

Fuel Delivery System

- Diesel/gas fuel pump
- Diesel/gas fuel injectors
- Fuel pressure regulator

Steering

All internal parts of:

- Steering gear box
- Steering rack & pinion unit (short rack)

Brakes

- Calipers
- Master cylinder
- Vacuum power assist booster
- Wheel cylinders

Air Conditioning

- Accumulator
- Clutch bearing
- Compressor
- Compressor clutch
- Compressor seals
- Condenser
- Evaporator
- Expansion valve
- Freon only in conjunction with a covered A/C repair
- Idler pulley
- Receiver/drier

Suspension

- Ball joints
- Coil & leaf spring
- Control arms
- Radius arms & bushings
- Spindle / knuckle
- Stabilizer bar bushings & links

Cooling

- Electric radiator cooling fan motor
- Fan clutch
- Heater core
- Radiator
- Thermostat

Rental

- Up to 3 days

Truck Gold

Includes all Truck Silver coverage and...

Engine

- Engine mounts
- Harmonic balancer & bolt
- Oil pan
- Timing & valve covers
- Vacuum pump

Turbo (Supercharger) ²

All internal parts:

- Bearings
- Supercharger housing
- Turbo charger housing
- Vanes
- Wastegate

Transmission

- Transmission mounts
- Transmission oil pan

Drive Axle

- Axle shafts
- Double offset joints
- Differential cover
- Drive axle housing ¹
- Drive shaft center bearings
- Propeller shaft
- Yokes
- 4WD locking hub

ABS

- Accumulator
- Electronic control processor
- Hydraulic pump
- Isolation dump valve
- Motor assembly
- Pressure modulator valve
- Wheel speed sensors

Brakes

- Hydroboost power assist unit

Rental

- Up to 5 days

Steering

All internal lubricated parts:

- Electric power steering motor
- Main & intermediate steering shafts & couplings
- Manual & power steering gear housing
- Power steering pump
- Steering column

Electrical / High Tech

- Ignition management controls:
 - AIT sensor
 - Camshaft & crank sensors
 - Coil pack(s)
 - Engine control module
 - Ignition control module
 - Knock sensor
 - MAF sensor
 - MAP sensor
 - O2 sensor
 - Powertrain control module
 - TPS sensor
 - Transmission input/output speed sensor
- Keyless entry transmitter & receiver
- Power mirror motor & motor switch
- Power seat switch
- Power window switch
- Windshield washer pumps (front & rear)

Diesel High Tech

- EGT sensors
- FICM
- Fuel pressure sensor
- NOx sensors
- Turbo speed sensor
- Waste gate sensor