

Preferred coverage to protect your new purchase.

- 24/7 Emergency Roadside Assistance*
- ASE-certified claims adjusters
- Approved claims paid in less than
 5 business days (after the work is complete)
- PWI only works with select dealerships that are known for quality, dependable pre-owned vehicles
- Rideshare friendly



BROKEN DOWN OR NEED REPAIRS?

Remember to call PWI first!

You must contact PWI **BEFORE** any repairs are made. Remember, you cannot submit a claim after repairs have been made. We can help you find a reputable repair shop to minimize your out-of-pocket expense or to help you get Emergency Roadside Assistance, if available with your Plan.*

2 ways to submit a claim:

- **1**. Call **800-548-1121** and have your PWI Customer Card available, if possible.
- **2.** Create or log in to your online PWI account at **preferredwarranties.com** to submit your claim online directly to an adjuster.



*Ask your Dealer for a complete copy of the service contract terms and conditions.

**This Contract is a service contract, and is not a warranty as that term is legally defined and commonly understood.

***SIRIUSXM Offer Details, visit siriusxm.com/PWI

*24/7 Emergency Roadside Assistance is not available in California

© 2022 Preferred Warranties, Inc. All rights reserved.

PWI.206 7/22

VEHICLE PROTECTION PLANS

Powertrain • Base • Plus

To file a claim: 800-548-1121 preferredwarranties.com

For general inquiries email: info@preferredwarranties.com



Base Plan Plus Plan Powertrain Plan Includes all Base coverage and... **Engine / Diesel Engine Transmission / Manual Engine Electrical Engine** Steering All internal lubricated parts: All internal lubricated parts: Flywheel/flex plate Alternator **Engine mounts** Electric power Camshaft & bearings **Bearings** Water pump Electric radiator cooling Harmonic balancer & steering motor Connecting rods & **Bushings** bolt Main & intermediate fan motor bearings Gears & shafts Oil pan steering shafts & Power door lock actuator **Fuel Delivery System** Crankshaft & bearings Main drive gear Power seat motors Timing & valve covers couplings Diesel fuel injectors Exhaust valves Main shaft Power window motors Vacuum pump Power steering pump Diesel fuel pumps Hvdraulic & solid lifters Shift forks Starter motor Steering column Fluid pressure regulator Intake valves Spacers Starter solenoid Steering shaft pivot joint Fuel injection Turbo (Supercharger) ² Main bearings Synchronizer drums Voltage regulator All internal parts: control module Windshield wiper motor • Main engine oil pump, Synchronizer Gas fuel injectors Bearings **Electrical / High Tech** gears & pickup screen Transmission case 1 (front & rear) Convertible top • Gas fuel pump • Supercharger housing • **Pistons** Metering valve/pressure Turbo charger housing power motor Piston rings & wrist pins • Fluids & Filters / regulator **Air Conditioning** • Vanes Electronic ignition module Rocker arms & shafts Accumulator Wastegate Idle air control motor & **Diagnostics** Timing belt & gears Clutch bearing valve Any fluids & filters Suspension • Timing chain Compressor Ignition coil pack & **Drive Axle** Ball ioints required for a covered Valve push rods • Compressor clutch distributor repair (excluding A/C • Control arms Axle shafts Valve springs & retainers Compressor seals Ignition management refrigerant) • Radius arms & bushings Center bearings Condenser controls: Double offset joints Reasonable diagnostic • Coil & leaf spring **Seals & Gaskets** Evaporator 0 AIT sensor Spindle / knuckle charges up to \$75 • Differential cover All internal lubricated parts: **Expansion valve** Camshaft & crank 0 Stabilizer bar Drive shaft center Cylinder head gasket 1 Idler pulley Transfer Case ¹ bushings & links sensors bearings Intake manifold gasket Receiver/drier 0 Coolant temperature Suspension air compressor Propeller shaft All internal lubricated parts: All other seals & gaskets sensor Yokes **Bearings** only in conjunction with 0 Knock sensor **Cooling System** 4WD locking hub **Drive Axle Bushings** a covered repair 0 MAF sensor Radiator Chains CV ioints 0 MAP sensor Thermostat Universal joints & wheel **Transmission** Gears 0 O2 sensor **Transmission /** Fan clutch Sleeves bearings **Transmission mounts** Powertrain control **Heater Core** Automatic Sprockets Transmission oil pan module All internal lubricated parts: Transfer case 1 Fluids & Filters / 0 TPS **Rental** Bands **ABS Diagnostics** Transmission input/ • **Bearings** Up to 3 days **Differential** Accumulator • Freon including with a output speed sensor Bell housing 1 • Electronic control All internal lubricated parts: • covered A/C repair Keyless entry transmitter **Bushings** Bearings processor & receiver Friction & steel Differential housing ¹ Hydraulic pump **Brakes** Power mirror motor & clutch plates Ring & pinion gears Isolation dump valve • **Calipers** motor switch Gears & shafts Spacers Motor assembly Master cylinder Power seat switch • Governor Pressure modulator Spider gears & • Vacuum power assist Power window switch • Lock-up converter valve side gears booster Windshield washer pumps Pump Wheel speed sensors Wheel cylinders (front & rear) • Servo unit Shift solenoids Steering **Rental** Solenoid pack All internal parts of: Up to 5 days Steel drums Steering gear box Torque converter Steering rack & pinion unit Transmission case 1 Valve body & plate

¹ Covered only if damaged by the failure of an internal lubricated part.

² Must be factory installed.