

red shield

protection plans

select

vehicle protection plans

WRAP

Premier

Premium

Preferred

Powertrain

engine

Pistons, Piston Rings, Crankshaft, and Main Bearings, Connecting Rods and Rod Bearings, Camshaft and Camshaft Bearings, Timing Chain, Timing Gears, Intake and Exhaust Valves, Valve Springs, Oil Pump, Push Rods, Rocker Arms, Hydraulic Lifters, Rocker Arm Shafts, Water Pump. Engine block and/or cylinder heads.

transmission / transaxle

All internally lubricated parts of Manual or Automatic Transmissions, including oil pump, oil drums, planetaries, sun gear and shell, shafts, bearings, side gears, carrier pinion gear, ring gear, shaft rail, forks, synchronizers, and Torque Converters

transfer case

All internally lubricated parts of the 4 x 4 Transfer Case.

drive axels

All internally lubricated parts. Drive Axle housing is also covered if damaged is caused by a breakdown of an internally lubricated part.

turbo / supercharger (factory only)

All internally lubricated parts of the factory installed turbo/supercharger.

air conditioning / heating system

Compressor; internal assembly including pistons, rods, bearings, valves and shafts; clutch; coil and pulley; orifice tube; condenser; evaporator; manual switches. (WRAP, Premier, Premium, and Preferred Plans). Expansion valve; dryer tank; accumulator; POA valve; hi/low pressure cut-off switch; ducts and outlet hoses; automatic temperature control programmer. (WRAP, Premier, and Premium Plans)

suspension

Upper and lower control arms, control arm shafts and bushings; upper and lower ball joints; steering knuckles; stabilizer shaft, link and bushings; kingpins and bushings; strut bar and bushings; spindles and spindle supports (WRAP, Premier, Premium and Preferred Plans).

MacPherson struts; shackle bushings and eye bushings; springs; torsion bars and bushings; stabilizer linkage and bushings; wheel bearings and seals; automatic leveling unit compressor, sensor and limiter valve. (WRAP, Premier, and Premium Plans).

steering

All internal parts in rack and pinion; all internal parts in recirculating ball housing; couplings; gear housing; power steering pump; steering main and intermediate shafts; power cylinder assembly; power steering cooler; control valve; Pitman arm; idler arm; tie rod ends; drag link/center link (WRAP, Premier, Premium and Preferred Plans). Control unit; actuator; mode selector; position sensor; rear tie rod assembly; rear gear assembly; cylinder barrel; center joint; pinion; power steering housing is covered if damaged by the Failure of an internal part (WRAP, Premier, and Premium Plans).

cooling system

Water Pump, Cooling Fan; Cooling Fan motors; and fan clutch (All plans except Powertrain Plus and Powertrain). Engine Cooling Fan and Motor; Fan Clutch; Belt Tensioner; Radiator; Heater Core; Thermostat; Blower Motor; Hot Water Valve; Engine Oil Cooler; Cooler Lines and Fittings (Premier Plus and Premium Plus Plans).

fuel system

Fuel Pump, Fuel Injection Pump, Metal Fuel Lines, Fuel Pressure Regulator, Fuel Sending Unit, and Fuel Gauge. (WRAP, Premier, Premium, and Preferred Plans). Fuel injector metering pump; fuel injectors; fuel distributor; diesel injection pump; fuel tank; metal fuel lines. (WRAP, Premier, and Premium Plans)

electrical

Alternator, voltage regulator, heater fan, starter motor, starter solenoid, and starter drive. Power window motors and regulator; power door lock actuators; power truck switch; and power antenna motor. Anti-detonation/knock sensor; ESC/EEC/ECM module; oxygen sensor; electronic module retard vacuum switch; electronic ignition module; igniter; electronic digital instrument cluster; digital driver information display and module; instrument panel printed circuit board.

enhanced electrical

MAF/MAP sensor; EGR valve; DPFE valve; remote keyless entry transmitter and receiver; heated side view mirror element; cruise control servo, module and transducer; compass; speed sensor; thermometer.

brake system






Master cylinder; power assist booster and valve; wheel cylinders; calipers; combination valve; steel lines and fittings; backing plates; vacuum assist booster pump; springs, clips and retainers; self adjusters; rear activators; parking brake linkage and cables. Note: Red Preferred Coverage does not include ABS systems (WRAP, Premier, Premium, and Preferred). Electronic control unit; anti-lock computer module; wheel speed sensors/exciters; proportioning valves; high pressure hydraulic pump; electro-hydraulic proportioning control valves; accumulator (WRAP, Premier, and Premium Plans)

seals and gaskets

Leaking seals and gaskets on any covered part listed above

exclusionary

An exclusionary plan is written so that the plan states everything is covered but a small list of excluded items



Benefits & Features

Emergency Roadside Assistance -

We pay for the cost of emergency roadside services, including:

- o Towing
- o Battery Jumpstarts
- o Flat Tire Changes
- o Fuel Delivery (You are responsible for fuel costs)
- o Lockout Assistance



A+ RATING



Rental Car Coverage

We pay for the expense of a rental car when your vehicle is being repaired for covered repairs.

Trip Interruption Benefits

In the event you experience a breakdown 100 miles away from your home, we will pay for a portion of your meals and lodging for covered repairs.

Nationwide Protection

All of our plans can be used nationwide, so if you are traveling and experience a breakdown, you can rest assured your plan will be accepted.

Transferable Coverage

If you sell your car, you can transfer the coverage to the new owner, which increases the value of your vehicle!