



LIFETIME DEDUCTIBLE

You pay the \$250 deductible ONCE in your lifetime, then you only pay a \$25 copay on all future covered repairs on this vehicle and on any other vehicles that you put a UCC policy on throughout the rest of your entire LIFETIME! Other deductible options are also available.



TOWING COVERAGE

When your vehicle experiences a mechanical breakdown, you can get reimbursed for towing expenses.

TRIP INTERRUPTION COVERAGE

If your vehicle breaks down when you are more than 100 miles away from home and the repair requires you stay overnight, we will reimburse you for lodging and meals while the covered repairs are completed.

RENTAL CAR REIMBURSEMENT

While your vehicle is in the repair shop for a covered repair, you may be reimbursed up to \$35 / day for the cost of a rental car.

FULL TRANSFERABILITY

Your coverage is fully transferable, which increases the value of your vehicle when you decide to sell your vehicle.

24 HOUR ROADSIDE ASSISTANCE

24-hour nationwide emergency roadside assistance to help you with changing a flat tire, opening a locked door, delivery of gasoline and jump start of your vehicle.

See your contract for specific details, exact coverages, exclusions and limitations.

Service Contract Protection Plans:

MAJOR COVERAGE (1-4) covers parts in the Powertrain:

- | | | | |
|---|--|---|--|
| <p>ENGINE</p> <ul style="list-style-type: none"> All internally lubricated parts Rod and main bearings Cam bearings Wrist pins Valve and valve guides Push rods and cam followers Timing chains and gears Balance shafts and bearings Timing belt and tensioner Timing chain cover Exhaust manifold | <ul style="list-style-type: none"> Supercharger drive pulley Supercharger/Turbocharger Crankshaft Camshaft Connecting rods Pistons Piston rings Rocker arms Water pump Oil pump assembly Fuel pump Valve retainers Valve covers | <ul style="list-style-type: none"> Waste gate actuator Waste gate Hydraulic or solid lash adjusters <p>TRANSMISSION/TRANSFER CASE</p> <ul style="list-style-type: none"> All internally lubricated parts Front pump Torque converter Governor Main shaft Bands Drums | <ul style="list-style-type: none"> Bushings Bearings Synchronizers Transfer case chain & gears Vacuum modulator valve <p>DRIVE AXLE</p> <ul style="list-style-type: none"> All internally lubricated parts Axle shafts Constant velocity joints Drive shafts Universal joints <p>SEALS & GASKETS of covered components</p> |
|---|--|---|--|

TOTAL COVERAGE (1-10) covers all parts under Major Coverage PLUS:

- | | | | |
|--|--|---|--|
| <p>ENGINE</p> <ul style="list-style-type: none"> Engine block Rotor housing Cylinder heads Thermostat <p>SUSPENSION</p> <ul style="list-style-type: none"> Upper & lower control arm shafts and bushings Upper & lower ball joints King pins Spindle & spindle supports Stabilizer bar Torsion bars Radius arms & bushings <p>STEERING</p> | <ul style="list-style-type: none"> All internally lubricated parts Rack & pinion assembly Control valve Power steering pump & pulley Power cylinder assembly Power steering cooler Pitman arm Idler arm Steering shaft & coupler <p>BRAKE SYSTEM</p> <ul style="list-style-type: none"> Master cylinder Wheel cylinders Metal brake lines & fittings Vacuum/hydraulic assist booster | <ul style="list-style-type: none"> Disc brake calipers Proportioning valve Backing plate Mounting hardware Self adjusters Brake pedal shaft <p>ELECTRICAL</p> <ul style="list-style-type: none"> Alternator Voltage regulator Starter motor & solenoid Wiper motors Wiper transmission Windshield washer pump Headlight & dimmer switch Cigarette lighter assembly Wiper switches | <ul style="list-style-type: none"> Ignition switch Turn signal switch Rear defroster switch <p>AIR CONDITIONING</p> <ul style="list-style-type: none"> Compressor Clutch Field coils & pulley Condenser Evaporator Expansion valve P.O.A. valve Blower motor Accumulator Receiver/drier & orifice tube <p>SEALS & GASKETS of covered components</p> |
|--|--|---|--|

TOTAL PLUS COVERAGE(1-11) covers all parts under Major and Total Coverage PLUS:

- | | | | |
|--|---|--|--|
| <p>HIGH TECH</p> <ul style="list-style-type: none"> Electronic instrument cluster Fuel injection modules & sensors Body computer Ignition module Electric convertible top motor Electric trunk lid actuator Electric window motors and regulators Electric seat motors Power antenna motor | <ul style="list-style-type: none"> Cruise control servo Air to air inter-cooler Anti-lock brake master cylinder/controller Clock Fuel distributor Fuel tank & metal lines Ignition coils & coil packs Distributor housing & shaft Locking hubs Engine mounts Transmission mounts | <ul style="list-style-type: none"> ABS pump & motor assembly Fuel pressure regulator Glove box lock and latch assembly Harmonic balancer Windshield washer nozzles Fuel injectors External transmission cooler Radiator fan, motor and clutch Heater control cable Sunroof motor Keyless entry control module | <ul style="list-style-type: none"> Electric door lock actuators Fuel door actuator Cruise control module All manually operated electrical switches Relays Wiring harnesses Tie rod ends Wheel bearings <p>SEALS & GASKETS of covered components</p> |
|--|---|--|--|

PLATINUM COVERAGE (1-12) Platinum is exclusionary coverage, which means that ALL PARTS AND COMPONENTS OF YOUR VEHICLE, INCLUDING LUXURY ELECTRONICS, ARE COVERED except for the items listed in the "What Is Not Covered" section of the contract. There are a few parts not covered by the Platinum Plan, such as, but not limited to:

- | | | | |
|------------------|----------------------------|-----------------------|---------|
| • Adjustments | • Belts & hoses | • Brake pads & shoes | • Paint |
| • Battery cables | • Tune up items/plug wires | • Carpet & Upholstery | • Glass |

WRAP Coverage (6-12) is exclusionary coverage which is designed to "wrap around" the manufacturer's warranty.