



## GOLD PLAN PROTECTION OFFERS:

### **MECHANICAL BREAKDOWN PROTECTION**

As vehicles age and mileage adds up, a breakdown is more likely to happen and repair costs can be expensive.

### **POWERTRAIN COVERAGE PLUS**

The Gold plan covers the powertrain plus components in the air conditioning, fuel system and electrical system.

### **ROADSIDE ASSISTANCE**

24-hour nationwide emergency roadside assistance to help you with towing your vehicle when a breakdown occurs.

### **ALTERNATE TRANSPORTATION**

While your vehicle is in the repair shop for a covered repair, you may be reimbursed up to \$25 / day for the cost of a rental car.

### **A COMPANY YOU CAN TRUST**

United Car Care maintains an A+ rating with the Better Business Bureau.

# GOLD PLAN

## Covered Components:

### **1. ENGINE**

All internally lubricated parts including: crankshaft, rod and main bearings, camshaft, cam bearings, connecting rods, wrist pins, pistons, piston rings, valves and replaceable valve guides, valve retainers, hydraulic or solid lash adjusters, rocker arms, push rods, cam followers, timing chains and gears, balance shafts and bearings; oil pump assembly, water pump. All internal parts within the supercharger/turbocharger housing. The engine block, cylinder barrels, cylinder heads, oil pan, engine oil dipstick, engine oil dipstick tube, timing cover/timing case, and valve cover are covered only if damaged by the failure of a covered internally oil lubricated engine part.

### **2. TRANSMISSION**

All internally lubricated parts contained within the transmission case including: front pump, torque converter, governor, main shaft, bands, drums, gear sets, bearings, bushings, synchronizers, vacuum modulator valve, internal linkage, transmission filler tube and dipstick. Transmission case housing, and torque converter housings are covered only if damaged by the failure of an internally oil lubricated covered part.

### **3. TRANSFER CASE**

All internally oil lubricated parts contained within the transfer case (excluding electrical items). The transfer case housing is covered only if damaged by the failure of an internally oil lubricated covered part.

### **4. DRIVE AXLE (FRONT & REAR)**

All internally lubricated parts contained within the drive axle housing; axle shafts. The drive axle housing is covered only if damaged by the failure of an internally lubricated part.

### **5. AIR CONDITIONING**

Compressor, clutch, field coils and pulley; expansion valve, P.O.A. valve; accumulator; receiver/drier; orifice tube; high/low pressure cut-off switches; pressure cycling switch.

### **6. ELECTRICAL**

Alternator, voltage regulator, starter motor, ignition switch, front and rear window wiper motor, headlamp switch, turn signal switch, rear defogger switch, heater/A.C. blower speed switch, power window motor, power door lock actuator and switch.

### **7. FUEL**

Fuel delivery pump, fuel injection pump (excluding diesel engines) and metal fuel delivery lines.

### **8. SEALS AND GASKETS**

Seals and gaskets are covered on a stand-alone basis in 1-4 above and in 5-7 above are covered only if required in connection with the repair or replacement of covered components/parts.

“Down the road... we’re there for you.”



## GOLD PLAN PROTECTION OFFERS:

### **MECHANICAL BREAKDOWN PROTECTION**

As vehicles age and mileage adds up, a breakdown is more likely to happen and repair costs can be expensive.

### **POWERTRAIN COVERAGE PLUS**

The Gold plan covers the powertrain plus components in the air conditioning, fuel system and electrical system.

### **ROADSIDE ASSISTANCE**

24-hour nationwide emergency roadside assistance to help you with towing your vehicle when a breakdown occurs.

### **ALTERNATE TRANSPORTATION**

While your vehicle is in the repair shop for a covered repair, you may be reimbursed up to \$25 / day for the cost of a rental car.

### **A COMPANY YOU CAN TRUST**

United Car Care maintains an A+ rating with the Better Business Bureau.

# GOLD PLAN

## Covered Components:

### **1. ENGINE**

All internally lubricated parts including: crankshaft, rod and main bearings, camshaft, cam bearings, connecting rods, wrist pins, pistons, piston rings, valves and replaceable valve guides, valve retainers, hydraulic or solid lash adjusters, rocker arms, push rods, cam followers, timing chains and gears, balance shafts and bearings; oil pump assembly, water pump. All internal parts within the supercharger/turbocharger housing. The engine block, cylinder barrels, cylinder heads, oil pan, engine oil dipstick, engine oil dipstick tube, timing cover/timing case, and valve cover are covered only if damaged by the failure of a covered internally oil lubricated engine part.

### **2. TRANSMISSION**

All internally lubricated parts contained within the transmission case including: front pump, torque converter, governor, main shaft, bands, drums, gear sets, bearings, bushings, synchronizers, vacuum modulator valve, internal linkage, transmission filler tube and dipstick. Transmission case housing, and torque converter housings are covered only if damaged by the failure of an internally oil lubricated covered part.

### **3. TRANSFER CASE**

All internally oil lubricated parts contained within the transfer case (excluding electrical items). The transfer case housing is covered only if damaged by the failure of an internally oil lubricated covered part.

### **4. DRIVE AXLE (FRONT & REAR)**

All internally lubricated parts contained within the drive axle housing; axle shafts. The drive axle housing is covered only if damaged by the failure of an internally lubricated part.

### **5. AIR CONDITIONING**

Compressor, clutch, field coils and pulley; expansion valve, P.O.A. valve; accumulator; receiver/drier; orifice tube; high/low pressure cut-off switches; pressure cycling switch.

### **6. ELECTRICAL**

Alternator, voltage regulator, starter motor, ignition switch, front and rear window wiper motor, headlamp switch, turn signal switch, rear defogger switch, heater/A.C. blower speed switch, power window motor, power door lock actuator and switch.

### **7. FUEL**

Fuel delivery pump, fuel injection pump (excluding diesel engines) and metal fuel delivery lines.

### **8. SEALS AND GASKETS**

Seals and gaskets are covered on a stand-alone basis in 1-4 above and in 5-7 above are covered only if required in connection with the repair or replacement of covered components/parts.

“Down the road... we’re there for you.”